

FreeSound

Magnetic Induction Loop

Our FreeSound headphones are equipped with a magnetic induction loop compatible with the "T" position per ear.

They are therefore compatible with all hearing aids compatible with the "T" position, and in stereo.

Remark:

What is the magnetic induction loop and the "T" position?

The magnetic loop is a listening aid system for hearing-impaired people who have one or two hearing aids with the activated T position.

This magnetic induction loop allows sounds to be transmitted directly to a hearing aid. Thus, ambient noise no longer disturbs understanding. Once the "T position" is activated, the person can only hear the sound coming from the magnetic loop.

The letter "T" comes from Telephone, which is the primary use of this magnetic loop.

The T-position program is initially activated by the hearing care professional. Then, on some prostheses the selection is made automatically, on others you have to use a push button to choose to use it, or an application on your smartphone.

You can then use the "T position" of your appliance

Warning: the "T position" is not systematically present on all devices, especially on the smallest devices that do not allow the presence of an induction coil.



FreeSound headphone jack

This socket marked T position allows the connection of FreeSound headphones and thus allows people equipped with hearing aids to listen to a message.